



PARTS PRICE LIST

ePedal Primo

Part number	Part Description	Price (UKP) ex. VAT
2102001	Frame	£80.00
2102002	Saddle	£20.00
2102003	Seat Post	£6.00
2102004	Seat Hoop	£4.00
2102005	Front Fork	£50.00
2102006	Cartridge Headset	£6.00
2102007	Handlebar	£20.00
2102008	Headset Stem	£40.00
2102009	Brake Bar	£16.00
2102010	Grips	£6.00
2102011	Front Light	£5.00
2102012	Rear Light	£4.00
2102013	Bottom Bracket	£4.00
2102014	Bottom Bracket Cups	£4.00
2102015	Winch & Sprocket Wheel	£30.00
2102016	Pedal	£7.00
2102017	Chain	£10.00
2102018	Shimano Shift Leverset	£12.00
2102019	Shimano Derailleur	£12.00
2102020	Shimano Gear	£20.00
2102021	Motor	£140.00
2102022	36V 10AH Battery	£260.00
2102023	Charger	£50.00
2102024	Controller	£50.00
2102025	Spoke	£20.00
2102026	Rim	£20.00
2102027	Tyre	£50.00
2102028	Front Hub	£8.00
2102029	V - Brake	£6.00
2102030	Front Disk Brake	£20.00
2102031	Brake Cable	£3.00
2102032	Bell / compass	£2.00
2102033	Reflector	£2.00
2102034	Mudguard	£6.00
2102035	Support	£6.00
2102036	Rear Rack	£50.00
2102037	Battery power indicator	£5.00
2102038	Front light switch	£3.00